

# EXPLMODE system variable

1544 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 2323

## Function Description:

The **EXPLMODE** system variable is used to control whether the EXPLODE command supports non-uniformly scaled blocks.

**Type** : Integer

**Saved in** : Not saved

**Initial value** : 1

**Range** : 0,1

## System Variable Value:

**0** : do not explode non-uniformly scaled blocks

**1** : explode non-uniformly scaled blocks

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1544>