REDRAWALL command

2318 GstarCAD MY /KW August 20, 2021 CAD Commands 0 2018

The **REDRAWALL** command is used to refresh display of all viewports.

Command Access:

Command: REDRAWALL

Function Description:

This command could remove temporary files left by the VSLIDE command or some other operations. Users could remove scattered pixels by the REGENALL command.

Online URL: https://www.kb2.gstarcad.com.my/article.php?id=2318