

SURFACEAUTOTRIM System Variable — GstarCAD 2027

SURFACEAUTOTRIM System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > S System Variables > SURFACEAUTOTRIM

Function Description:

The SURFACEAUTOTRIM system variable is used to set whether to auto trim surface when geometry projecting to surface.

Type	Integer
Saved in	Registry
Initial value	0
Range	0,1

System Variable Value:

- 0:** do not trim surface when geometry projecting to surface.
- 1:** auto trim surface when geometry projecting to surface

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4304>