

3DOSMODE System Variable — GstarCAD 2027

3DOSMODE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The 3DOSMODE system variable is used to control 3D object snap settings.

Type	Integer
Saved in	Registry
Initial value	11
Range	0 ~ 256

System Variable Value:

- 1:** all 3D object snaps are disabled. **Shortcut key:** ZNON
- 2:** snap a vertex or a control point. **Shortcut key:** ZVER
- 4:** snap a middle point on a face edge. **Shortcut key:** ZMID
- 8:** snap the center point on a face. **Shortcut key:** ZCEN
- 16:** snap a knot of a spline or surface. **Shortcut key:** ZKNO
- 32:** snap a vertical face(planar faces only). **Shortcut key:** ZPER
- 64:** snap an object nearest to a face. **Shortcut key:** ZNEA
- 128:** snap the nearest point on planar segment of point cloud. **Shortcut key:** PNOD
- 256:** all 3D object snaps are disabled. **Shortcut key:** PNEA

Note this system variable can control which 3D object snap enabled. The setting is stored as a bitcode using the sum of listed system variable values.
Users can specify more than one object snap by entering the sum of their values. Taking 6 for example, it means to specify the vertex and middle point object snaps.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4951>