

BACKZ System Variable — GstarCAD 2027

5045 kbadmin September 25, 2026 [Command Reference](#) 0 9

BACKZ System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The BACKZ system variable is used to set the offset value from clipping plane to target plane when saving current viewports by drawing units.
(Read-Only)

Type	Integer
Saved in	Drawing
Initial value	0.0000

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5045>