

CELTYPE System Variable — GstarCAD 2027

5093 kbadmin September 25, 2026 [Command Reference](#) 0 15

CELTYPE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The CELTYPE system variable is used to set new object linetypes.

Type	Strings
Saved in	Drawing
Initial value	BYLAYER

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5093>