

HPANG System Variable — GstarCAD 2027

5597 kbadmin September 26, 2026 [Command Reference](#) 0 6

HPANG System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The HPANG system variable is used to set the angle of new hatch pattern,

Type	Integer
Saved in	Not saved
Initial value	0.0000

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5597>