

SURFTAB2 System Variable — GstarCAD 2027

5970 kbadmin September 26, 2026 [Command Reference](#) 0 16

SURFTAB2 System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The SURFTAB2 system variable is used to set the mesh density in N direction for REVSURF command.

Type	Integer
Saved in	Drawing
Initial value	6

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5970>