GFANG system variable

Function Description:

The **GFANG** system variable is used to specify the angle of gradient fill.

Type : Real
Saved in : Not saved
Initial value : 0
Range : 0 ~ 360