LENSLENGTH system variable

Function Description:

The **LENSLENGTH** system variable is used to store the length of the lens in millimeters used in perspective viewing.

Type : Real
Saved in : Drawing
Initial value : 50.000