MATERIALSPATH system variable

Function Description:

The **MATERIALSPATH** system variable is used to specify the path for materials library. (Read-Only)

Type : Strings
Saved in : Users-settings
Initial value : Unknown

Online URL: https://www.kb2.gstarcad.com.my/article.php?id=1695