PUBLISHHATCH system variable

Function Description:

The **PUBLISHHATCH** system variable is used to control whether hatch patterns of DWF or DWFx published is treated as a single object.

Type : Integer
Saved in : Registry
Initial value : 1
Range : 0,1

System Variable Value:

0 : when publish DWF or DWFx formats, hatch patterns group is treated as each single object
1 : when publish DWF or DWFx formats, hatch patterns group is treated as a single object

Online URL: https://www.kb2.gstarcad.com.my/article.php?id=1783