BSAVE command

The **BSAVE** command is used to save current block definition.

Command Access:

Command : BSAVE

Function Description:

This command could only be used in block editor. It could save all changes of current block definition.