Get Selection by Object/Layer

Select entities by entity type and layer.

Menu : Express>Selection Tools>Get Selection by Object/Layer

Command Entry : getentlaysel

Operation steps:

1.Start the command.

2.Select one object and system will take the object layer as target layer.

3.Specify region.

4.System will select the objects which are in the same layer and with same entity type automatically.