

ACTPATH System Variable — GstarCAD 2027

ACTPATH System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > A System Variables > ACTPATH

Function Description:

The ACTPATH system variable is used to specify the additional paths to load action macros for playback.

Type	Strings
Saved in	Registry
Initial value	""

Note: users should input semicolons to separate paths if specified multiple paths.

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)