

GRIPBLOCK System Variable — GstarCAD 2027

GRIPBLOCK System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > G System Variables > GRIPBLOCK

Function Description:

The GRIPBLOCK system variable is used to control the display of grips in blocks.

Type	Integer
Saved in	Registry
Initial value	0
Range	0,1

System Variable Value:

- 0:** only specify grids for insertion points of block
- 1:** specify grids for insertion objects of block

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

