

TEXTSIZE System Variable — GstarCAD 2027

TEXTSIZE System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > T System Variables > TEXTSIZE

Function Description:

The TEXTSIZE system variable is used to set the default text height for new created text objects.

Type	Real
Saved in	Drawing
Initial value	Real 0.2000(Imperial) or 2.5000(Metric)

The TEXTSIZE will be not available if there is a fixed text height in current text style.

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)