

PDSIZE System Variable — GstarCAD 2027

PDSIZE System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > P System Variables > PDSIZE

Function Description:

The PDSIZE system variable is used to set the display size of point objects.

Type	Real
Saved in	Drawing
Initial value	0.0000

System Variable Value:

- 0:** create points at 5 percent of the drawing area height
- >0:** specify the absolutely size
- <0:** specify a percentage of viewport size

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

