

SHOWMOTIONPIN System Variable — GstarCAD 2027

SHOWMOTIONPIN System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > S System Variables > SHOWMOTIONPIN

Function Description:

The SHOWMOTIONPIN system variable is used to control the default status of thumbnail images.

Type	Integer
Saved in	Registry
Initial value	1
Range	0,1

System Variable Value:

- 0:** display thumbnail snapshot in an unpinned state
- 1:** display thumbnail snapshot in pinned state

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

