

DIMALT System Variable — GstarCAD 2027

DIMALT System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > D System Variables > DIMALT

Function Description:

The DIMALT system variable is used to control the display of alternate units in dimensions.

Type	Parameter
Saved in	Drawing
Initial value	Turn off

System Variable Value:

- Off:** disable alternate units
- On:** enable alternate units

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)