

DIMCLRE System Variable — GstarCAD 2027

DIMCLRE System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > D System Variables > DIMCLRE

Function Description:

The DIMCLRE system variable is used to specify color for extension lines, center marks, and center lines.

Type	Integer
Saved in	Drawing
Initial value	0

In "Select Color" dialog box, input "0" to select "BYBLOCK"; input "256" to select "BYLAYER".

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)