

DIMSE1 System Variable — GstarCAD 2027

DIMSE1 System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > D System Variables > DIMSE1

Function Description:

The DIMSE1 system variable is used to control whether to hide the first extension line.

Type	Parameter
Saved in	Drawing
Initial value	Off

System Variable Value:

Off: display the extension line

On: hide the extension line

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)