

DIMTFILL System Variable — GstarCAD 2027

DIMTFILL System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > D System Variables > DIMTFILL

Function Description:

The DIMTFILL system variable is used to control the background of dimension text.

Type	Integer
Saved in	Drawing
Initial value	0

System Variable Value:

- 0: no background
- 1: background of graphic
- 2: specified by DIMTFILLCLR system variable

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

