

To Attach a DWF or DWFx Underlay — GstarCAD 2027

6101 kbadmin September 26, 2026 [Command Reference](#) 0 14

To Attach a DWF or DWFx Underlay

[GstarCAD 2027](#) · [Command Reference](#)

To Attach a DWF or DWFx Underlay

1. Click Insert > DWF Underlay on the main menu.
2. The Select Reference File dialog box is displayed, in which you can select the file to attach.
3. The Attach DWF Underlay dialog box is displayed, select one sheet, or use SHIFT or CTRL to select multiple sheets.
4. Select Specify On-Screen to use the pointing device to attach the DWF underlay at the Insertion Point, Scale and Rotation. You can also clear Specify On-Screen and enter values under Insertion Point, Scale, or Rotation.
5. Click OK.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6101>