

To Chamfer a 3D Solid — GstarCAD 2027

6109 kbadmin September 26, 2026 [Command Reference](#) 0 9

To Chamfer a 3D Solid

[GstarCAD 2027](#) · [Command Reference](#)

To Chamfer a 3D Solid

1. Click Modify > Solid Editing > Chamfer Edge on the main menu.
2. Select the edge to chamfer. A preview of the chamfer is displayed.
3. You can do one of the following:
 - Select another edge on the same face to chamfer.
 - Specify the Loop option if you want all the edges of a face to be chamfered. Select another edge on the same face.
4. Specify the distances for the base surface and the other, adjacent surface.
5. You can do one of the following:
 - Press Enter to accept the chamfer.
 - Enter the Distance option to change the values.
6. To complete the chamfer, press Enter.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6109>