

To Convert a Spline to a Polyline — GstarCAD 2027

6138 kbadmin September 26, 2026 [Command Reference](#) 0 11

To Convert a Spline to a Polyline

[GstarCAD 2027](#) · [Command Reference](#)

To Convert a Spline to a Polyline

1. Click Modify > Object > Spline on the main menu.
2. Select the spline to convert.
3. Enter P (convert to Polyline) at the command prompt.
4. Specify a precision.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6138>