

To Create a Solid by Offsetting a Surface — GstarCAD 2027

6178 kbadmin September 26, 2026 [Command Reference](#) 0 13

To Create a Solid by Offsetting a Surface

[GstarCAD 2027](#) · [Command Reference](#)

To Create a Solid by Offsetting a Surface

1. Click Draw > Modeling > Surfaces > Offset on the main menu.
2. Select surfaces or regions to offset.
3. Enter S (Solid) at the command prompt.
4. Specify the offset distance.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6178>