

Startup system Variable

1134 kbadmin April 3, 2016 [System Variables](#) 0 5938

This system variable toggles on/off the Startup dialog box to help users to setup drawing templates settings. Using this dialog box is safer. It will make them aware to select a template before actually start to draw. You can set this startup dialog box to open everytime when you start GstarCAD, Just type STARTUP [enter] then type 1 as new value then [enter]. You can also choose not to open new file or dialog box. You can set STARTUP system variable to 2.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1134>