

How to Adjust Size from an Inserted Table?

1173 kbadmin October 13, 2016 [Tips & Tricks](#) 0 5799

Once you inserted a blank table, click any edge of the table. You'll notice blue grips at the ends of the table and also around it. So you can resize (enlarge) width, height by holding and dragging the blue grips.



Learn : [Table](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1173>