

## APERTURE command

1212 kbadmin June 30, 2021 [Setting / Configuration](#) 0 4470

The APERTURE command is used to controls the size of the object snap target box.

### Command


APERTURE *(or aperture for transparent use)*

### Command Prompts


Enter new value for APERTURE<10>:

### Function Description:

The object snap could be applied on objects in the object Aperture box or objects that intersect with the object Aperture box. Users could get a bigger Aperture size by setting a higher value for APERTURE system variable, as well control whether to display it by APBOX command. Those settings could also be made in “draw” label in “Options” dialog box.




aperture:5




aperture:20

The APERTURE command could control object Aperture box rather than Pick box that displayed under the command prompt of “select object”.



Pickbox: 3



Pickbox:10

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1212>