

# APERTURE command

1212 kbadmin June 30, 2021 [Setting / Configuration](#) 0 5463

The APERTURE command is used to controls the size of the object snap target box.

## Command

APERTURE *(or aperture for transparent use)*


### Command Prompts

Enter new value for APERTURE<10>:


### Function Description:

---

The object snap could be applied on objects in the object Aperture box or objects that intersect with the object Aperture box. Users could get a bigger Aperture size by setting a higher value for APERTURE system variable, as well control whether to display it by APBOX command. Those settings could also be made in “draw” label in “Options” dialog box.




aperture:5




aperture:20

The APERTURE command could control object Aperture box rather than Pick box that displayed under the command prompt of “select object”.



Pickbox: 3



Pickbox:10

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1212>