

ACTRECPATH system variable

1313 GstarCAD MY /KW July 7, 2021 [System Variables](#) 0 3642

Function Description:

The **ACTRECPATH** system variable is used to specify paths for storing new action macros.

Type : Strings

Saved in : Registry

Initial value : Unknown

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1313>