

BPARAMETERFONT system variable

1351 GstarCAD MY /KW July 8, 2021 [System Variables](#) 0 3869

Function Description:

The **BPARAMETERFONT** system variable is used to set the font used for parameters and actions in block editor.

Type : Strings

Saved in : Registry

Initial value : Arial

Users could specify either a True Type font or a SHX font (such as Verdana or Verdana.ttf). They must add the .shx extension to a font. When specifying an Asian Big Font, using the following naming convention: an SHX file followed by a comma, followed by the Big Font file name(such as txt .shx, Bigfont .shx).

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1351>