

# CECOLOR system variable

1359 GstarCAD MY /KW July 9, 2021 [System Variables](#) 0 4162

## Function Description:

The **CECOLOR** system variable is used to set color for new objects.

**Type** : Strings

**Saved in** : Drawing

**Initial value** : BYLAER

The following are valid value:

**BYLAYER** or **BYBLOCK**;

Index Color: an integer ranges from 1 to 255, or names of one of front seven colors;

True Color: a RGB or HSL value ranges from 000 to 255, the format is "RGB: 000,000,000" Color

Books: the standard **PANTONE** or customized color systems, DIC color books or RAL color sets.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1359>