

DIMLFAC system variable

1460 GstarCAD MY /KW July 13, 2021 [System Variables](#) 0 2637

Function Description:

The **DIMLFAC** system variable is used to set scale factors for linear dimension measurements.

Type : Real

Saved in : Drawing

Initial value : 1.0000

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1460>