

DIVMESHCONEXIS system variable

1496 GstarCAD MY /KW July 14, 2021 [System Variables](#) 0 2136

Function Description:

The **DIVMESHCONEXIS** system variable is used to set the number of subdivisions for basal plane circumference of mesh cone.

Type : Parameter

Saved in : User-settings

Initial value : 8

This setting could affect the new mesh cone created by **MESH** command. This value could also be set in "Mesh Primitive Option" dialog box.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1496>