

## GCADVER system variable

1576 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 2340

### Function Description:

The **GCADVER** system variable is used to store versions number.

**Type** : Strings

**Saved in** : Not saved

**Initial value** : Unknown

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1576>