

GCADVER system variable

1576 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 2447

Function Description:

The **GCADVER** system variable is used to store versions number.

Type : Strings

Saved in : Not saved

Initial value : Unknown

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1576>