

GFNAME system variable

1582 GstarCAD MY /KW July 15, 2021 [System Variables](#) 0 2277

Function Description:

The **GFNAME** system variable is used to specify the pattern of a gradient fill.

Type : Integer

Saved in : Not saved

Initial value : 1

Range : 1,2,3,4,5,6,7,8,9

System Variable Value:

1 : linear

2 : cylindrical

3 : inverted cylinder

4 : spherical

5 : hemispherical

6 : curved

7 : inverted spherical

8 : inverted hemispherical

9 : inverted curved

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1582>