

# GRIPCOLOR system variable

1591 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 2247

## Function Description:

The **GRIPCOLOR** system variable is used to control the color for unselected grips.

**Type** : Integer

**Saved in** : Registry

**Initial value** : 150

**Range** : 1 ~ 255

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1591>