

GRIPDYNCOLOR system variable

1593 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 2489

Function Description:

The **GRIPDYNCOLOR** system variable is used to control the display color of custom grids for dynamic blocks.

Type : Integer

Saved in : Registry

Initial value : 140

Range : 1 ~ 255

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1593>