

# GRIPHOT system variable

1594 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 2242

## Function Description:

The **GRIPHOT** system variable is used to control the color of selected grip.

**Type** : Integer

**Saved in** : Registry

**Initial value** : 12

**Range** : 1 ~ 255

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1594>