

# GRIPMULTIFUNCTIONAL system variable

1596 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 2716

## Function Description:

The **GRIPMULTIFUNCTIONAL** system variable is used to control the access way for multiple function grip option.

**Type** : Bitcode

**Saved in** : Registry

**Initial value** : 3

**Range** : 0,1,2,3

## System Variable Value:

**0** : the multiple function grip option is disabled

**1** : access multiple function grip option by CTRL to change grip behaviors(cycle change object editing ways by pressing CTRL key )

**2** : access multiple function grip option by displaying grip menu when cursor hovering on grips

**3** : access multiple function grip option by CTRL or displaying grip menu

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1596>