

HPBACKGROUNDCOLOR system variable

1613 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 2517

Function Description:

The **HPBACKGROUNDCOLOR** system variable is set the background color of hatch pattern.

Type : Strings

Saved in : Registry

Initial value : None

Valid values:

"None" or "." to apply no background color
Index Color: an integer between 1 and 255, or color name of the front seven colors

True Color: a RGB or HSL value between 000 and 255, the format is "RGB:000,000,000"

Color Books: standard color system, wizard, and set text

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1613>