

INETLOCATION system variable

1634 GstarCAD MY /KW July 16, 2021 [System Variables](#) 0 2239

Function Description:

The **INETLOCATION** system variable is used to store the internet website which used by **BROWSER** command and "Browser Web" dialog box.

Type : Strings

Saved in : Registry

Initial value : "http://www.gstarcad.net"

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1634>