

# PICKSTYLE system variable

1748 GstarCAD MY /KW July 23, 2021 [System Variables](#) 0 3069

## Function Description:

The **PICKSTYLE** system variable is used to control the use of group selection and associative hatch selection.

**Type** : Integer

**Saved in** : Registry

**Initial value** : 1

**Range** : 0,1,2,3

## System Variable Value:

**0** : do not use the group selection and associative hatch selection.

**1** : use the group selection

**2** : use the associative hatch selection.

**4** : use the group selection and associative hatch selection.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1748>