PLINEGEN system variable

Function Description:

The **PLINEGEN** system variable is used to control the way to generate linetype pattern around the vertices of a 2D polyline.

Type : Integer
Saved in : Drawing
Initial value : 0
Range : 0,1

This settings is not suitable for the polyline with tapered segments.

System Variable Value:

0 : generate the linetype beginning and ending with dash at each vertex of the polyline
1 : generate the linetype beginning and ending with dash at each vertex of the polyline

Online URL: https://www.kb2.gstarcad.com.my/article.php?id=1751