

POLYSIDES system variable

1761 GstarCAD MY /KW July 23, 2021 [System Variables](#) 0 2721

Function Description:

The **POLYSIDES** system variable is used to set default edge number for POLYGON command.

Type : Integer

Saved in : Not saved

Initial value : 4

Range : 3 ~ 1024

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1761>