

PREVIEWFILTER system variable

1765 GstarCAD MY /KW July 23, 2021 [System Variables](#) 0 2015

Function Description:

The **PREVIEWFILTER** system variable is used to exclude specified object types from selection preview.

Type : Bitcode

Saved in : Registry

Initial value : 7

Range : 0 ~ 63

The setting is stored as a bitcode using the sum of listed system variable values.

System Variable Value:

0 : exclude nothing

1 : exclude objects on locked layers

2 : exclude objects in xrefs

4 : exclude tables

8 : exclude Mtext objects

16 : exclude hatch pattern objects

32 : exclude objects in groups

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1765>