

PROJECTNAME system variable

1769 GstarCAD MY /KW July 23, 2021 [System Variables](#) 0 2463

Function Description:

The **PROJECTNAME** system variable is used to specify project name for current drawing.

Type : Strings

Saved in : Drawing

Initial value : ""

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1769>